

Environmental Test Chambers



Delta Design Environmental Test Chambers

Rugged, dependable, precision instruments designed with testing and processing ease in mind.

The Delta Design 9000 Series
Temperature Chambers offer a
wide choice of temperature
ranges and capacities in addition
to smart electronics. Fieldproven by satisfied customers for
over four decades, Delta
chambers are quality instruments
that provide service longevity
and integrity unique in their
field.

Over the years, Delta has added advanced features to the proven basic chamber design and has refined system components and programming capability to deliver outstanding quality and value.

The Delta family of precision chambers range in test volume from 1/3 cubic foot to 5-3/4 cubic feet, delivering ranges of from -73°C to +315°C, precisely controlled by advanced electronic circuitry. And each chamber is equipped with an adjustable over-temperature protection device.

All chambers are temperature expandable to -184°C, utilizing optional LN₂ cooling. Standard chamber coolant is 1050 psi LCO₂. Models 9059 and 9064 have a 1-1/4" diameter access port on the left side. The Model 9076 has three 7/8" diameter access ports in the rear.

Each chamber is equipped with a Model 9010 temperature controller that allows a program to be repeated up to 9,999 times. Each program step consists of temperature, time and rate of change parameters. Soak time can be up to 100 hours. Built-in controller external interfaces provided are IEEE-488 and RS232. The controller features pushbutton convenience, backlit LCD, battery-backed memory and settable bus address and baud rates. An optional programmer, Model 9020, is available for more extensive test routines.

Standard Temperature Chamber includes:

- Model 9010 Controller with built-in 10-step programmer
- Thermometer CO2 hose/filter
- 1050 psi CO2 valve Instruction manual

Standard Specifications:

- Temperature Accuracy-Setpoint to actual ±1.0°C
- Temperature Deviation-After Stabilization ±0.1°C
- Repeatability ±0.25°C
- Line Voltage Stabilization ±0.25°C for 105-125VAC
 - or 220-240VAC line voltage change
- Failsafe Adjustable over-temperature



	9023	9028	9039	9059	9064	9076
Test Volume	0.37 cubic feet (10.5 liters)	0.45 cubic feet (12.7 liters)	0.92 cubic feet (26.05 liters)	1.85 cubic feet (52.4 liters)	2.2 cubic feet (62.3 liters)	5.78 cubic feet (163.7 liters)
Internal Dimensions	8"H x 10"W x 8"D (20.32 x 25.40 x 20.32 cm)	7"H x 16"W x 7"D (17.78 x 40.64 x 17.78 cm)	10"H × 16"W × 10"D (25.40 × 40.64 × 25.40 cm)	11"H x 19.5"W x 15"D (27.94 x 49.53 x 38.10 cm)	12"H x 20"W x 16"D (30.48 x 50.80 x 40.64 cm)	20"H × 20"W × 25"D (50.80 × 50.80 × 63.50 cm)
Overall Dimensions	12.75"H x 17.5"W x 20.75"D (32.38 x 44.45 x 52.70 cm)	12.25"H × 28.75"W × 20.875"D (31.11 × 73.02 × 53.02 cm)	17.875"H x 27.5"W x 24"D (46.40 x 69.85 x 60.96 cm)	17.25"H x 32"W x 25"D (43.82 x 81.28 x 63.50 cm)	21.5"H × 32.875"W × 30.0"D (54.61 × 83.66 × 76.20 cm)	36.25"H × 38.25"W × 37.5"D (92.08 × 97.16 × 95.3 cm)
Temperature Range	-73°C to +315°C or -100°F to +600°F OPTION -184°C (-300°F) with optional LN ₂	-73°C to +315°C or -100°F to +600°F OPTION -184°C (-300°F) with optional LN ₂	-73°C to +315°C or -100°F to +600°F OPTION -184°C (-300°F) with optional LN ₂	-73°C to +315°C or -100°F to +600°F OPTION -184°C (-300°F) with optional LN ₂	-73°C to +315°C or -100°F to +600°F OPTION -184°C (-300°F) with optional LN ₂	-73°C to +315°C or -100°F to +600°F OPTION -184°C (-300°F) with optional LN ₂
Heat-up Rate	24°C / minute	20°C / minute	14°C / minute	10°C / minute	8°C / minute	8°C / minute
Cool-Down Rate	31°C / minute	25°C / minute	36°C / minute	22°C / minute	20°C / minute	12°C / minute
LCO ₂ Consumption	5.6 lbs / hr @ -53°C (-65°F)	6.5 lbs / hr @ -53°C (-65°F)	7 lbs / hr @ -53°C (-65°F)	9.62 lbs / hr @ -53°C (-65°F)	11.6 lbs / hr @ -53°C (-65°F)	15 lbs / hr @ -53°C (-65°F)
Air Circulation	Vertical air flow pattern	Horizontal air flow pattern	Vertical air flow pattern	Horizontal air flow pattern	Vertical air flow pattern	Horizontal air flow pattern
Power Requirements	120VAC, 50 or 60 Hz, single Ø, 1800W 208VAC, 50 or 60 Hz, 3-wire, single Ø, 1800W 208VAC, 50 or 60 Hz, 4-wire, single Ø, 1800W 240VAC, 50 or 60 Hz, single Ø, 1800W	120VAC, 50 or 60 Hz, single Ø, 1800W 208VAC, 50 or 60 Hz, 3-wire, single Ø, 1800W 208VAC, 50 or 60 Hz, 4-wire, single Ø, 1800W 240VAC, 50 or 60 Hz, single Ø, 1800W	120VAC, 50 or 60 Hz, single Ø, 1800W 208VAC, 50 or 60 Hz, 3-wire, single Ø, 1800W 208VAC, 50 or 60 Hz, 4-wire, single Ø, 1800W 240VAC, 50 or 60 Hz, single Ø, 1800W	120VAC, 50 or 60 Hz, single Ø, 1800W 208VAC, 50 or 60 Hz, 3-wire, single Ø, 1800W 208VAC, 50 or 60 Hz, 4-wire, single Ø, 1800W 240VAC, 50 or 60 Hz, single Ø, 1800W	120VAC, 50 or 60 Hz, single Ø, 1800W 208VAC, 50 or 60 Hz, 3-wire, single Ø, 1800W 208VAC, 50 or 60 Hz, 4-wire, single Ø, 1800W 240VAC, 50 or 60 Hz, single Ø, 1800W	208VAC, 50 or 60 Hz, 3-wire, single Ø, 4800W 208VAC, 50 or 60 Hz, 4-wire, single Ø, 4800W 240VAC, 50 or 60 Hz, single Ø, 4800W
Net Wt. (approx.)	47 lbs (21.3 Kg)	55 lbs (24.9 Kg)	85 lbs (38.6 Kg)	98 lbs (44.5 Kg)	115 lbs (52.2 Kg)	232 lbs (105.9 Kg)
Shipping Wt. (approx.)	47 lbs (21.3 Kg)	70 lbs (31.8 Kg)	100 lbs (45.4 Kg)	105 lbs (47.6 Kg)	235 lbs (106.6 Kg)	413 lbs (188.5 Kg)

Doors

Delta offers a wide variety of doors to fit all standard chamber models. When ordering a specific door type, please specify that number (1 through 7, assigned for that door model in the descriptions below) with your order. If you do not want a door, please specify "0."

1 Blank with Tray Available for Models 9023,



Blank—No Trav Available for Models 9059, 9076*

I Ten 3/8" dia. Ports with Tray Available for Models 9023,

9039

4 Window and Five 3/8" dia. Ports with Tray Available for Models 9023,



5 Ten 3/8" dia. Ports —No Tray Available for Models 9059,



6 Window Door for Chamber Model 9076

9015 CONTROLLER



9015 Programmer provides automatic sequencing for temperature testing and temperaturedependent processing.

program parameters controlled are Rate of Temperature Change, Soak Time, Temperature Setpoint and Deviation Limits, and the Number of Passes.

OPTIONS

Additionally, three relays are provided for turning external devices on and off. The state of the three relays is programmable for each segment. Program parameters are

entered by front panel buttons with data displayed on an LCD. The program is stored in a battery-backed memory in the event of power loss and

temperature resolution of 0.1°C; retrieved when power is restored. The program may have soak time from 1 minute to 99 up to 30 segments and may be hours, 59 minutes; rate of repeated up to 9999 times 99.9°/minute maximum and before being automatically shut process deviation limits of 2° to 99.9° or no limits.

A program review function is The programmer incorporates provided to allow the operator a settable process deviation limit alarm with a front panel to sequentially step through all program parameter for the indicator and alarm output at current segment may be the rear panel. displayed without disturbing the

A "program lock" position is provided with removable key to safeguard the entered program.

9911 TEMPERATURE MONITOR



Monitoring of temperature excursions between two preset limits is provided by the Temperature Monitor. If limits are exceeded, power to the monitor unit is removed, a warning lamp is illuminated, and an audible alarm is Centigrade ranges.

activated. When temperature is again within limits, the monitor may be reset for continued operation. A combination pyrometer scale provides reading at a glance with both Fahrenheit and

9145 BURN-IN SYSTEM

The Delta Design Burn-In System utilizes a versatile circuit board approach which allows the mounting of any combination of device sockets. An internal load rack design accommodates a density of greater than one device per cubic inch of chamber space (for Connector for each board 14-pin DIP devices), mounted in a useable space of 7" x 10" per board. The environmental chamber provides flexible rear wall seals which allow the circuit board connectors of the

device under test to be outside the high temperature environment.

The Model 9145 comprises: Temperature Chamber with Controller; Cart; Power Control Module: Chamber Door: Internal Rack for PC boards: 6-Pin PC position with three wires from each connected to a bus bar. The cart assembly provides standard rack mounting space for instruments and power

Operating temperature range is +40°C to +315°C and -73°C to +315°C using optional CO2 or LN2 coolant. The chamber design provides temperature gradients of ±3°C up to +150°C.

operation. Setpoint can range

from -184°C to +135°C with a

Additional features:

Adjustable Mechanical Over-Temperature Loss of Airflow Protection Device Ambient Air Venting Power Control Module with Automatic Shutdown Mounting Space for Power Supplies and

CARTS



is an open framework design and is used with a Model 9076 chamber. The Model 9904 Cart holds a test chamber and two 50-pound LCO2 siphon bottles. It is used with a Model 9023,

9028, 9039, 9059, or 9064 test two of which swivel and are

Delta Design ERIES

Environmental Test Chambers





DELTA DESIGN, INC.

12367 Crosthwaite Circle, Poway, CA 92064-6817 858-848-8000 Fax 858-848-8180 info@deltad.com

WWW.DELTAD.COM